


Remove the parts clearly from runner. When there's burr, remove them with nail clippers or scissors.

1 Each material parts has a different mark. Check the mark and number of each parts.

A①	A②	A③
		Each octopus parts has a different shape. The following octopus parts are assembled for material parts A①~A⑤. [octopus parts A] All octopus sucker parts have O surface.



2 Let's build up the material parts as it fits perfectly. The material parts need to be held. Assemble it while holding the parts in your hands.

※ Assemble A① and A④ first, and put the octopus sucker parts as it fits firmly. Keep the ★ side up and proceed to **2**.



2 When all the material parts are assembled correctly, assemble the sauce parts with their 4 bumps to the material parts.


[Here's the source parts from the back side.]



3 Each material parts has a different mark. Check the mark and number of each parts.


B①	B②	B③
		Each octopus parts has a different shape. The following octopus parts are assembled for material parts B①~B⑤. [octopus parts B] There is one octopus sucker that does not have a dump surface.

[Comparison diagram of octopus parts A and octopus parts B]





2 Let's build up the material parts as it fits perfectly. The material parts need to be held. Assemble it while holding the parts in your hands.

※ Assemble A① and A④ first, and put the octopus sucker parts as it fits firmly. Keep the ★ side up and proceed to **4**.



4 When all the material parts are assembled correctly, assemble the sauce parts with their 4 bumps to the material parts.

[Here's the source parts from the back side.]



5 **Complete!**



When all parts are put together without a gap, you're success!
 ※let's complete 2 Takoyaki!!

Incorrect...



If there is a gap between the parts or the source parts are not assembled firmly, please try it again.


When the parts don't fit firmly...

- The combination of material parts is wrong.
- The combination of material parts, octopus parts, and source parts is wrong.
- The direction in assembling the material parts, octopus parts, and source parts is wrong.

Please check the above.

Please try again from the beginning if you cannot make Takoyaki.

6 Assemble the display source parts into the display material parts.



Accessories

●Display the takoyaki on a paper craft boat.



※Toothpicks are not included in the contents.

Paper Craft Boat